



User Guide

Thermal Comfort System (TCS)®

INSTALLER: To be removed for use by the occupant

Always check www.americh.com for the most updated operating instructions.

CAREFULLY READ AND FOLLOW ALL INSTRUCTIONS

before attempting to operate your whirlpool or Airbath® Bathtub.

IMPORTANT SAFETY INSTRUCTIONS: pertaining to a risk of fire, electric shock, or injury to persons

Warning: Whirlpool bathtubs utilize acrylic and fiberglass materials (which are inherently slippery surfaces), electricity, water, air pressure and suction. The following basic safety precautions should always be followed when using your bathtub.

READ AND SAVE THESE INSTRUCTIONS

ELECTRICAL REQUIREMENTS


Manufacturer recommends a dedicated 20 amp circuit breaker for each power cord supplied on your whirlpool bathtub. **WARNING** - When using electrical products, basic precautions should always be followed, including the following:

1. **DANGER: Risk of electric shock.** Connect only to a supply circuit protected by a Class A ground-fault circuit-interrupter (GFCI). Test on a routine basis.
2. Grounding is required. The unit should be installed by a qualified service representative and grounded.
3. (For built-in and custom units) install to permit access for servicing.
4. Supply 110 Volt electrical outlet. This circuit must be protected by a ground fault circuit interrupter (GFCI.)

5. Plug supply cord(s) into electrical outlet.
6. To test the GFCI, do the following:
 - a. Push the test button;
 - b. Check to see that power has been interrupted;
 - c. Push the reset button;
 - d. Check to see that power has been restored.

If the GFCI does not operate properly during the test, there is a ground current flowing indicating the risk of electric shock. Do not use this unit. Disconnect the unit and have the problem corrected by a qualified service representative before using.

Refer to Operating Instructions for system operations and wiring diagrams.



System Temperature

- 1st Press: Press and hold to power on. TCS will heat to 90°.
- 2nd Press: TCS heats to 104°.
- 3rd Press: TCS turns off.

*Thermal Comfort System requires 10-15 minutes to reach heat level.

Auto-Off Function

Thermal Comfort System has a 30 minute auto-off function that allows you to safely enjoy a bathing system like no other. The TCS is eco-friendly and consumes less energy than a common 60 watt light bulb.